Instruction Manual: Swell

What does Swell do?

- Boat Cover tension: The inflatable design keeps your boat cover tight, so rainwater doesn't pool like a stagnant pond.
- Mold and Mildew Defense: Constant airflow keeps things breezy, combating mold and mildew from making themselves at home.
- Pest Deterrent: What do pests hate most? Minty scents, airflow, and subtle vibrations. What does Swell provide? You guessed it: Minty scents, constant airflow, and subtle vibrations. Consider pests evicted.

Installation & Use

No tools needed: Swell comes pre-assembled.

Quick Start Instructions:

- 1. Put Swell in your boat with you boat cover installed.
- **DO NOT CONNECT/TIGHTEN COVER STRAPS UNTILL SWELL IS FULLY INFLATED**
- 2. Pull a few feet of fabric out to ease inflation.
- 3. Plug it in and adjust if needed.
- 4. Toss the Scent Booster in your boat.
- 5. Fire up the grill and cook a ribeye, you earned it. Good job.

Detailed Instructions:

Go ahead and get your boat cover installed on your boat.

Step 1: DO NOT OPEN THE LID!

Just kidding, we know you already did. Congratulations, you nailed Step 1. Heck yeah, we're off to a good start.

Step 2: Check the Packet

The packet that includes these instructions has a few key items inside.

- 1. A Ball Magnet
- 2. A Captain-head Scent Booster (air freshener)
- ---Set those aside for now, we'll come back shortly

Step 3: Power Cord Prep

Grab the power cord and controller assembly from the box. It's pre-attached so don't play tug-of-war with it. Just get the slack of the cord out of the box.

Tip: Swell won't power on?

Check the quick-release safety connectors on the power cord, **there are 2**. They're designed to prevent damage from accidental tugs. One is easily visible 3 ft from the controller, the other is located underneath the inflatable fabric, close to the fan. Open a zipper to access.



*DO NOT YANK ON THE FABRIC. The inflatable portion is packed, folded, and pre attached in the box. No need to break things; we're only on Step 3. Geez.

Step 4: Pull out some fabric

Gently pull a few feet of fabric from Swell's base. Locate the magnet attached to the fabric. That is the top/center of the inflatable. That little guy will come in handy soon.

Step 5: Position Swell in the Boat

Place Swell under your boat cover and keep it within reach for now. Pull out another foot of fabric and let the power cord/controller assembly hang over the gunwale (that's the "edge").

Step 6: Connect the Magnets

Remember the ball magnet from Step 2? Grab it.

- · Place the ball magnet on top of your boat cover.
- Lift the magnet attached to the fabric (from Step 4) under the cover and let the two connect. Enjoy that click.

Step 7: Center Swell

Get Swell as centered as possible on your boat deck. Those magnets should line up nicely over the cabin. If you don't feel like climbing in, use a pole to nudge Swell into place (maybe that old extension pole you just replaced...)

Step 8: Power on

Alright, Here goes nothing...Grab that extension cord and Plug it in.

• **Pro Tip**: Make sure your boat cover straps are loose until Swell fully inflates.

Step 9: Adjust

Use the knob on the controller to adjust airflow.

Swell has 6 zipper vents around its circumference. These control airflow and how rigid Swell gets, or how easily it molds around your boat seats.

- o Start at full power with a few vents partially open.
- o Once inflated, lower power to \sim 50% and adjust the vents further. Many people settle at \sim 30% power.

Step 10: Add the Scent Booster (Final Step)

Remember the Captain-head air freshener from Step 2? Tie the Scent Booster string through the eyehole on one of Swell's zipper tabs, remove the plastic protector, and take a whiff. That's victory.



